

## Introduction

The DSLR-1 camera plug-in v1.0 software provides integrated photo capture support for the following Canon digital single lens reflex (DSLR) cameras used with Polaroid ID Card Maker photo ID software.

Canon EOS-1D Mark III
Canon EOS 40D
Canon EOS-1Ds Mark III
Canon EOS 450D/Rebel XSi
Canon EOS 1000D/Rebel XS
Canon EOS 5D Mark II
Canon EOS 50D
Canon EOS 500D/Rebel T1i
Canon EOS 7D
Canon EOS-1D Mark IV
Canon EOS 550D/Rebel T2i

## Camera Configuration Notes

1. Use the **"P"** mode setting.
2. Open the camera's internal flash before starting the configuration editor or ID application.
3. Set the camera's **"Auto Power-off"** option to **"Off"**. *If it is left on, the camera will shut off its power after inactivity. The software cannot automatically turn the camera power back on so the user will have to manually power on the camera if it has powered off.* <Menu button – move over 4 selections>
4. Change camera's **"LCD off/on button"** option to **"Shutter/DISP"**. <Menu button – move over 4 selections and down 5 selections>
5. Navigate to camera's **"Live View function settings"** and change **"Live View Shoot"** to **"Enable"**. <Menu button – move over 5 selections and down 5 selections>
6. Change **"Auto Rotate"** to **"Off"**. <Menu button – move over 4 selections and down 3 selections>